

Mobile Operations Control System for Central Operations Management in Dangerous Areas



Funksysteme Meyer

Operations control



In connection with the operations station.
Vehicle 12 V = 11 – 30 V vehicle connection

The 12 V of vehicle board mains connection may be used only in vehicles with negative ground. The power for the board net should lie above 11 V.

The operations control disposes of the same reception and control functions as the control case.

Fa. Funksysteme Meyer

Johannisstr. 4, D-06556 Artern

Phone: +49 (0) 3466 323444

Fax: +49 (0) 3466 323443

Mail: info@einsatzleitsystem.de

www.Einsatzleitsystem.de

Website is accessible in several languages, including English

Owner & CEO: Otto Meyer

EU VAT ID: DE150465422